

Specification and Installation Instructions

Model

SHS80-300 (Duct-Mount High-Limit Humidistat)

Description

The SHS80-300 is capable of sensing, monitoring and controlling relative humidity in the supply or return air duct. Its primary function is to act as both a 0-10 Vdc humidity sensor and an On/Off high limit protection or On/Off return duct humidistat.

Features

- On/Off high limit humidistat with on-board setpoint adjustment
- Built-in humidity transmitter (0-10 Vdc)
- Status LED & High Limit On/Off LED



SHS80-300

Technical Specifications

Description		SHS80-300
Power supply		24 Vac or Vdc ±10%
Power consumption		1 VA
Electrical connection		0.8 mm ² [18 AWG] minimum
Humidity transmitter output		0-10 Vdc (0-100 %RH)
Humidity sensor precision		±3% at 40 %RH and 23°C [73°F]
On/Off high limit setpoint range		20 to 90 %RH
Operating temperature		-40°C to 80°C [-40°F to 176°F]
Weight		0.35lb [160g]
Contact rating		Dry contact, 1A max, 24 Vac
Working temperature		0°C to 60°C [32°F to 140°F], <95% RH (without condensing)
Storage temperature		-10°C to 50°C [14°F to 122°F], 0-95% RH
Status LED (right)		Flashes if the device is powered on. Turns OFF if the device is powered off.
High Limit On/Off LED (left)		Turns ON if there is a high limit cutout (0V). Turns OFF if there is no high limit cutout (24V).
Dimensions		
A = 3.50" B = 3.00" C = 2.16" D = 1.30" E = 3.95" F = 0.37" G = 0.44" H = 0.80" I = 0.75"	89mm 76mm 55mm 33mm 100mm 9.5mm 11mm 20mm 19mm	A B B C C F G G

Mounting Instructions

Install the SHS80-300 directly on the supply air duct using the accessories. For standard humidifier applications, power the unit using the 24 Vac power supply provided from the humidifier.

This product is subject to the terms and conditions described at http://www.neptronic.com/Sales-Conditions.aspx.



Any installation or maintenance work must be carried out by suitably qualified personnel.

Dis


Disconnect the main supply on the unit and external loads before proceeding with any installation or maintenance.

SHS80-300-210518-ESA Page | 1



Specification and Installation Instructions


Wiring Diagrams



Page | 2 www.neptronic.com




Specification and Installation Instructions



www.neptronic.com Page | 3




Specification and Installation Instructions



www.neptronic.com Page | 4




Specification and Installation Instructions



www.neptronic.com Page | 5



Specification and Installation Instructions



www.neptronic.com

Notes	



Recycling at end of life: please return this product to your Neptronic local distributor for recycling. If you need to find the nearest Neptronic authorized distributor, please consult **www.neptronic.com**.



neptronic

400 Lebeau blvd, Montreal, Qc, H4N 1R6, Canada www.neptronic.com

Toll free in North America: 1-800-361-2308

Tel.: (514) 333-1433 Fax: (514) 333-3163

Customer service fax: (514) 333-1091 Monday to Friday: 8:00am to 5:00pm (Eastern time)