



neptronic®
www.neptronic.com

- HVAC Controls
- Electric Actuators
- Actuated Valves
- Humidifiers
- Electric Heaters


Head Office
Neptronic®
400 Lebeau Blvd.
Montreal, Quebec, Canada H4N 1R6
Tel.: (514) 333-1433
Fax: (514) 333-3163
Toll Free: 1-800-361-2308

CMU: The Basics of the MAC Board

Neptronic's Make-Up Air Controller, referred to as MAC, serves as a fundamental component within our innovative Compact Make-Up Air Unit (CMU).

The MAC board, which can be called the brain of the CMU, helps the system in enhancing the Indoor Air Quality (IAQ) by delivering air that is fresh, filtered, and pre-heated through ductwork. However, while the technical specifications of the CMU, such as airflow requirements and heating capacities, are pivotal in selecting the appropriate model for a given application, the effectiveness of these units ultimately relies on their control strategies.

In this article, we discuss the standard features of the CMU by delving into the MAC board's basic control capabilities.



Remote Temperature Sensor Connection

The remote temperature sensor connection is a critical aspect of the CMU's functionality, ensuring accurate temperature monitoring for effective operation. By default, the CMU is equipped with a remote temperature sensor, and users can choose between two types: the STC8-11 discharge air duct temperature sensor, or the STR1-11 room air temperature sensor.

The remote temperature sensor must be appropriately wired to its designated terminal block on the MAC board even if the COM board is used for the application. Failure to establish this connection results in the CMU not initiating its operational cycle.


IMC10 Connection

The IMC10 connection on the MAC board of the CMU serves as a key feature for additional control and interlocking capabilities.

The MAC board has a designated terminal block specifically for connecting an IMC10 room control switch. If no IMC10 is used, a jumper must be placed between pins 1 and 2 of that T-block (done by default at the factory). Alternatively, the two pins (1 and 2) on the terminal block can be repurposed as an enable/disable contact (e.g., by wiring an SIH-150 current switch to interlock the CMU with an exhaust fan). If the circuit between pins 1 and 2 opens, it results in the CMU being disabled.

Fan Speed and Temperature Setpoint Adjustment

Central to the MAC board's capabilities are two essential potentiometers. The first, P1, allows for the adjustment of fan speed, providing users with the flexibility to tailor airflow to specific requirements. Meanwhile, P2 allows users to set and fine-tune temperature setpoints, ensuring precise control over the heating of the CMU system. The minimum fan speed achievable via P1 depends on the type of fan the unit came with: The minimum fan speed for AC is 75% and for ECM, it is 15%.



Damper Actuator Connection:

During normal operation, the MAC board within the CMU closes an internal, 24VAC-rated dry contact which is capable of handling up to 1A of current. This terminal block can be used to drive a damper actuator or even as an auxiliary switch to start any other remote device based on the application's needs (e.g., an exhaust fan).

Add-On PCB Connection:

The MAC board boasts a dedicated terminal, strategically positioned to integrate with the CMU-COM add-on control board. This addition serves as a gateway to a realm of advanced control strategies thanks to its configurable Inputs and Outputs (I/Os), connection for a remote TDF user-interface module and BACnet/Modbus communication.

Although optional for CMUs with AC fans, if an AC model was ordered without the COM board, it can be added in the future, making the “basic” CMU upgradeable for advanced control strategies and/or BACnet/Modbus integration.

This board comes standard on all CMUs equipped with Electronically Commutated Motor (ECM) fans.

Status LED Sequence:

The Status LED (LD1) on the MAC offers an intuitive output sequence to indicate specific alarm types. By providing a clear method of conveying alarm information, the MAC ensures that users can navigate troubleshooting effortlessly.

Status	LED Output
Remote Temperature Sensor Fault	Blinks 5 times and stays ON for 5 seconds.
Electronic Airflow Sensor Fault	Blinks 10 times and stays ON for 10 seconds.
Automatic/Manual Cut-out Trip	Blinks 15 times and stays ON for 15 seconds.
Normal Operation	Blinks once every 2 seconds.
Other Scenarios can include: 1. Error in Feedback for ECM Fans 2. Incorrect configuration of the IO's on the COM board 3. Communication error between the Add-on and Host Boards 4. No heat detection (when failing to achieve the desired temp. setpoint within the programmed delay and dead band) And so on.	LED stays on continuously till the alarm is reset.

Remote viewing/identification of any triggered alarm is possible with the add-on CMU-COM circuit board by connecting it to a Neptronic TDF controller or a communication network (BACnet/Modbus). For more information on our Compact Make-Up Air Unit, please refer to the relevant CMU documents on our [Documentation page](#)



Mamun Sattar
Technical Support – Heating
Contact him at: mamun@neptronic.com

About Neptronic

At Neptronic, we pride ourselves in our ability to adapt to diverse applications. We have been at the heart of humidification innovation since 1976 to help enhance process efficiency and end-result quality by generating the ideal ambient conditions for our customers' needs.

Committed to research and development, we constantly aim to improve reliability and precision of our products. Our dedicated team of over 300 experts works in Montreal, Canada to create the ideal solutions for your applications.